

1



Ensure work area is clear of all personnel.

2



Attach rigging to bottom. Tip the trench box on its side.

3



Remove rigging from top of box. Ensure gravity latches are disengaged.

4



Remove bottom strut pin.

5



Remove strut pin on other side.

6



Pull the panel and strut assembly over until perpendicular to the ground.



7

**Remove strut pins from both sides of second panel.**



  
**Keep slight tension on rigging**



8

**Lower panel flat to the ground.**



9

**Attach rigging to strut lift points.**



10

**Remove latch pins.**



11

**Lift the struts free from the panels**



12

**Move rigging to the top of the strut and place in strut stands.**